



Deuschmann

your ticket to all buses

**Quick Start
EtherCAT TwinCAT V3 from BECKHOFF
with Deuschmann UNIGATE® EtherCAT**

1	Download the TE1000 TwinCAT 3 software	2
2	ESI (EtherCAT Slave Information)	3
2.1	ESI - UNIGATE® CL, CM, CX, EL and MB:	3
2.2	ESI - UNIGATE® IC and IC2	3
3	Start TwinCAT V3	4
4	Selected device found	10
5	New device found or mismatch with ESI file	15
6	Input and Output Modules	22
6.1	Input and Output modules configured via EtherCAT Master	22
7	Reload Device Description	24
8	Servicing	25
8.1	Returning a device	25
8.2	Downloading PC software	25

Disclaimer of liability

We have checked the contents of the document for conformity with the hardware and software described. Nevertheless, we are unable to preclude the possibility of deviations so that we are unable to assume warranty for full compliance. The information given in the publication is, however, reviewed regularly. Necessary amendments are incorporated in the following editions. We would be pleased to receive any improvement proposals which you may have.

Copyright

Copyright (C) Deutschmann Automation GmbH & Co. KG 1997 – 2022. All rights reserved.


This document may not be passed on nor duplicated, nor may its contents be used or disclosed unless expressly permitted. Violations of this clause will necessarily lead to compensation in damages. All rights reserved, in particular rights of granting of patents or registration of utility-model patents.

EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

1 Download the TE1000 | TwinCAT 3 software

TwinCAT 3.1 – eXtended Automation Engineering (XAE)

<https://www.beckhoff.com/en-en/support/download-finder/software-and-tools/>



2 ESI (EtherCAT Slave Information)

After installation, copy the device description file (ESI file) into following folder:

C:\TwinCAT\3.1\Config\Io\EtherCAT

Note: Depending on the ESI file used, the I/O sizes are either fixed or modular (configurable via EtherCAT master). An ESI file with modular I/O sizes was used to create this guide.

2.1 ESI - UNIGATE® CL, CM, CX, EL and MB:

An ESI file can be generated via the WINGATE configuration software if the "Universalscript Deutschmann" loaded in the delivery state is available in the devices.

Note: A sample device description file (ESI file) for which the I/O sizes can be configured via the EtherCAT master can be requested using the support form on the Deutschmann website.

Attention: UNIGATE® CM and EL have been discontinued since 12/2018.

2.2 ESI - UNIGATE® IC and IC2


The sample device description file (ESI file) provided can be used as a basis for creating your own device description file. Deutschmann Automation also offers the creation as a service.

Note: The sample device description file (ESI file) is sent once with the first order. Further information regarding the creation of your own device description file can be found in the attached document 'esiQuickStart'.

3 Start TwinCAT V3




Check if your Ethernet Card is working with the software



If there is a device shown in the subfolder „Installed and ready to use devices“, you can go on. If not, it must be added using the "Install" button.

Note: The devices listed here are examples and may have different names.




Either the "Universalscript Deutschmann" (not for IC+IC2), the template script for EtherCAT (part of the software Protocol Developer) or a customer-specific script must be loaded in the UNIGATE®.

- Universal script Deutschmann: Among other things, the I/O sizes can be configured via the WINGATE configuration software.
- Template EtherCAT: Initially, 8 bytes I/O are set. These can be changed using the Protocol Developer software. The template is also the perfect basis for creating your own script.
- Custom Script: Function dependent on programming.


Then the UNIGATE® can be started in data exchange mode.

Note: If the UNIGATE® is started in configuration mode, 8 Byte I/O is set automatically.

Starting a new project.




Assign a project name and click „OK“.



Scanning devices

Click right mouse button and select “Scan”. Then click “OK”.

Note: If it is not possible to select “Scan”, please, check whether TwinCAT is started in config mode.




Config mode is indicated by the blue background of the config icon in the status bar.




If the config icon is highlighted in red TwinCAT is not in config mode.







Select device and click „OK“. If no device appears, check the Ethernet connection.




Click „Ja“.



If this window appears, the ESI file does not match the scanned hardware. Click, no and a new Box will be generated. For further instructions see chapter „New device found or mismatch with ESI file“.




Click „Ja“ .



4 Selected device found

The selected device was found → UNIGATE® IC.



Select the I/O size

Note: The I/O size must match the setting in the user script.

In the template script, 8 Byte I/O is set. This means, 8 Byte for input and 8 Byte for output must be set via the slots.

E.g. It is possible to use a 1 Byte input module 8 times. Or only one 8 Byte input module. The same applies for output.


The screenshot shows the TwinCAT configuration interface with the 'Slots' tab selected. The top window displays a list of slots with 'Unigate' modules for input and output. The bottom window shows a detailed list of modules for input and output, with '8 Byte Array Out' selected.

Slot	Module	ModuleIdent
[Icon] Unigate	in	0x00000008
[Icon] Unigate	out	0x00080000
[Icon] Unigate		
[Icon] Unigate		
[Icon] Unigate		
[Icon] Unigate		
[Icon] Unigate		
[Icon] Unigate		
[Icon] Unigate		
[Icon] Unigate		
[Icon] Unigate		
[Icon] Unigate		
[Icon] Unigate		
[Icon] Unigate		
[Icon] Unigate		
[Icon] Unigate		
[Icon] Unigate		
[Icon] Unigate		
[Icon] Unigate		

☒ Download SlotCfg ☐ (I->P)

Module	ModuleIdent	Description
[Icon] Input(Slave to SPS)		
[Icon] in	0x00000001	1 Byte In
[Icon] in	0x00000002	1 Word In
[Icon] in	0x00000004	1 DWord In
[Icon] in	0x00000008	8 Byte Array In
[Icon] in	0x00000010	16 Byte Array In
[Icon] in	0x00000020	32 Byte Array In
[Icon] in	0x00000040	64 Byte Array In
[Icon] in	0x00000080	128 Byte Array In
[Icon] Output(SPS to Slave)		
[Icon] out	0x00010000	1 Byte Out
[Icon] out	0x00020000	1 Word Out
[Icon] out	0x00040000	1 DWord Out
[Icon] out	0x00080000	8 Byte Array Out
[Icon] out	0x00100000	16 Byte Array Out
[Icon] out	0x00200000	32 Byte Array Out
[Icon] out	0x00400000	64 Byte Array Out
[Icon] out	0x00800000	128 Byte Array Out


After that, click „Reload Devices“.




Now the device is in operational mode and the selected I/O sizes are available.

Name	Online	Type	Size	>Addr...	In/Out	User
8 byte Input(AR...	0x0000000000000000...	ARRAY [0.....	8.0	39.0	Input	0
WcState	0	BIT	0.1	1522.1	Input	0
InputToggle	0	BIT	0.1	1524.1	Input	0
State	8	UINT	2.0	1548.0	Input	0
AdsAddr	10.10.10.1.3.1:1001	AMSADDR	8.0	1550.0	Input	0
8 Byte Output(A...	0x0000000000000000...	ARRAY [0.....	8.0	39.0	Output	0

Serial data can be sent to the UNIGATE® UART via the Starter Kit software module RS232.




The serial data is displayed in the input data.



5 New device found or mismatch with ESI file

Double click on Box 1 (P00000E5B R00000002).



Select „EtherCAT“ and „Advanced Settings...“

General **EtherCAT** Process Data Startup CoE - Online Online

Type:

Product/Revision:

Auto Inc Addr:

EtherCAT Addr:

Identification Value:

Previous Port:

Open „Smart View“ and click the button „Write EProm“...

Advanced Settings

General Mailbox Distributed Clock ESC Access E²PROM Configured Station Enhanced Link De **Smart View** Hex Editor FPGA Memory

Smart View

Config Data (evaluated from ESC)

EPROM Size (Byte):

PDI Type:

☐ Device Emulation (state machine emulation)

SPI / 8 / 16 μ C Interface

☐ BUSY Open Drain ☐ BUSY High Active

☐ INT Open Drain ☐ INT High Active

32 Bit Interface

☐ WD Open Drain ☐ WD High Active

☐ Input Latch

Sync Signal Configuration

☐ SYNC0 Open Drain ☐ SYNC0 High Active

☐ SYNC0 Enabled ☐ SYNC0 to PDI IRQ

☐ SYNC1 Open Drain ☐ SYNC1 High Active

☐ SYNC1 Enabled ☐ SYNC1 to PDI IRQ

Impulse Length (μ s):

Device Identity (hex)

Vendor Id:

Product Code:

Revision No.:

Serial No.:

Product Revision:

Mailbox

☐ CoE ☐ SoE ☐ EoE ☐ FoE

☐ AoE

Bootstrap Configuration

Out Start/Length:


In Start/Length:

Standard Configuration

Out Start/Length:


In Start/Length:

Select the desired ESI file and click OK. The EPROM is rewritten.




Note: If the file you are looking for is not displayed, the device descriptions must be reloaded. (see chapter 7 for more.)


After the description of the EPROM, the advanced settings can be closed with "OK".




Then remove Box 1



After that, the connected devices must be scanned again.



A new Box 1 (UNIGATE® IC) appears.




Depending on the ESI file, the sizes of input and output are either permanently stored in the ESI file or can be configured via TwinCAT. If the sizes of input and output are permanently stored in the ESI file, the device should be now in operational mode.

If not, the sizes of input and output must be configured via EtherCAT master. For more see chapter 6.1.


6 Input and Output Modules

6.1 Input and Output modules configured via EtherCAT Master


To configure the input and output modules, the "Slots" menu item must be selected.



Now the device is in operational mode




If the I/O size are subsequently changed, the button “Reload Devices” must be clicked.



7 Reload Device Description

A device description file (ESI file) can be reloaded via the menu point “TWINCAT” → “EtherCAT Devices” → “Reload Device Descriptions”.



Note: Only files that were in the following folder before TwinCAT was started are displayed.

C:\TwinCAT\3.1\Config\Io\EtherCAT

8 Servicing

Should questions arise that are not covered in this manual you can find further information in our

- FAQ/Wiki area on our homepage www.deutschmann.com or directly in our Wiki on www.wiki.deutschmann.de

If your questions are still unanswered please contact us directly.

Please note down the following information before calling:

- Device designation
- Serial number (S/N)
- Article number
- Error number and error description

Your request will be recorded in the Support center and will be processed by our Support Team as quickly as possible (Usually in 1 working day, rarely more than 3 working days.).

Technical Support hours are as follows:

Monday to Thursday from 8 am to midday and from 1 pm to 4 pm, Friday from 8 am to midday (CET).

Deutschmann Automation GmbH & Co. KG
Carl-Zeiss-Straße 8
D-65520 Bad-Camberg
Germany

Central office and sales department	+49 6434 9433-0
Technical Support	+49 6434 9433-33

Fax sales department	+49 6434 9433-40
Fax Technical Support	+49 6434 9433-44

E-mail Technical Support	support@deutschmann.de
--------------------------	--

8.1 Returning a device

If you return a device, we require as comprehensive a fault/error description as possible. We require the following information in particular:

- What error number was displayed?
- What is the supply voltage (± 0.5 V) with Gateway connected?
- What were you last doing or what last happened on the device (programming, error on power-up, ...)?

The more precise information a fault/error description you provide, the more exactly we will be able to pinpoint the possible causes.

8.2 Downloading PC software

You can download current information and software free of charge from our Internet server.
<http://www.deutschmann.com>

